



The MimioCapture™ ink recorder works seamlessly with the MimioTeach™ interactive whiteboard to capture dry erase whiteboard notes in real time.



Expo® dry erase markers insert directly into MimioCapture styli.



The ergonomically designed markers and erasers recharge quickly on the charging tray.



Status Light

Off: The MimioCapture pen or eraser is not receiving power. The battery needs to be recharged.

Solid Amber: The MimioCapture pen or eraser has a low battery. The battery should be recharged.

Solid Green: The MimioCapture pen or eraser is in the tray and charging.

